

Mail to: P.O. Box 1690, Pleasanton, CA 94566

Ship to: 440 Boulder Court, Suite 100C, Pleasanton, CA 94566

Dynamic Mixer PMX98 Parts

0514	Motor brushes (pair)	12.93
0601	Bearing	12.93
0607	Double lip waterproof seal	16.86
0726	Motor bearing Spring	1.82
089959	Wall Bracket	18.87
0908	Non-locking switch	27.07
0950	Strain relief bushing	2.26
0950.1	Strain relief bushing	2.26
0972	Capacitor (115v)	12.79
0972.1	Capacitor and filter (230v)	14.81
1017	Warning label	4.54
1027	Dynamic Label	11.26
1063	Label w/serial number	4.73
1064	Label w/serial number	4.73
1189	Support for lower bearing	20.64
1213	Variable control w/button	89.60
1214	Variable control w/button	77.85
7903	Spacer screws (4)	4.19
7913.F	Spacers (4)	14.57
7916	Lower bearing assembly	32.42
8309	Shaft	67.74
8313	Cutter blade	34.23
9023	Field spacer screws (2)	3.42
9025	Motor Bearing Sleeve	3.95
9040	Power cord (2 wire) (1	21.22
9502	Handle Screws (3)	0.56
9810.1	Complete handle (115v)	60.49
9811	Half lower handle w/label	26.34
9811.1	Half lower handle w/label	26.34
9812	Half upper handle	23.64
9813	Switch protector	7.80
9816	Motor & shaft housing	138.10
9817	Upper motor casing	40.31
9818	Fan	9.30
9819.1	Motor armature (115v)	218.14
9820.1	Motor Field (115v)	218.14
9821	Complete foot assembly	264.00
9836	Shaft lower bearing &am	114.40
9902	Lower bearing screws (3)	1.06



Mail to: P.O. Box 1690, Pleasanton, CA 94566

Ship to: 440 Boulder Court, Suite 100C, Pleasanton, CA 94566

Dynamic Mixer PMX98 Parts

