

Mail to: P.O. Box 1690, Pleasanton, CA 94566

Ship to: 440 Boulder Court, Suite 100C, Pleasanton, CA 94566

Dynamic Mixer PP97 Parts

| | | |
|---------|-------------------------------|--------|
| 0504 | Motor brushes (pair) | 12.93 |
| 0601 | Bearing | 12.93 |
| 0609 | Waterproof Seal | 15.07 |
| 0726 | Motor bearing Spring | 1.82 |
| 0745 | Pin 3 x 14 | 1.82 |
| 0768 | Safety button return spring | 3.57 |
| 0830 | Rubber Washer | 12.78 |
| 0835 | Pusher Blade | 113.09 |
| 0836 | Friction washer | 13.04 |
| 0842 | Ricer Grid / Blade Protector | 158.32 |
| 0881 | Wall bracket | 7.55 |
| 0950 | Strain relief bushing | 2.26 |
| 0950.1 | Strain relief bushing | 2.26 |
| 0965 | Switch (115v) | 34.32 |
| 0972 | Capacitor (115v) | 12.79 |
| 1027 | Dynamic Label | 11.26 |
| 1057 | ID Label (115v) | 4.73 |
| 7908.31 | Motor armature (115v) | 206.00 |
| 7933 | Fan | 8.23 |
| 8317 | Spacers screws (4) | 4.19 |
| 8322 | Screws w/ground washer | 0.78 |
| 8323 | Fan | 8.23 |
| 8428 | Out Shaft w/ Gear | 138.42 |
| 8429 | Double Gear with Washer | 109.34 |
| 8830 | Fork Axle | 18.41 |
| 9002 | Half handle button side | 50.57 |
| 9005 | Safety button | 2.73 |
| 9009 | Plug (deactivates switch) | 2.73 |
| 9010 | Control lever | 11.87 |
| 9014 | Handle screws (4) | 0.60 |
| 9015 | Motor housing brush holder | 68.48 |
| 9023 | Field spacer screws (2) | 3.42 |
| 9026 | Spacers (4) | 14.57 |
| 9038 | Motor field (115v) | 183.11 |
| 9040 | Power cord (2 wire) (1 | 21.22 |
| 9112 | Speed control plug | 1.86 |
| 9143 | Ground wire (115v) | 8.60 |
| 9700.1 | Complete Handle (115v) | 146.17 |
| 9707 | Complete Foot Assembly | 357.05 |
| 9708 | Variator cap | 1.84 |
| 9708.1 | Carbon brush wires (115v) (2) | 8.55 |
| 9709 | Plate w/ 2 Seals | 28.89 |
| 9730 | Half Handle Label Side | 51.86 |
| 9740 | Half Handle Label Side | 51.86 |



Mail to: P.O. Box 1690, Pleasanton, CA 94566

Ship to: 440 Boulder Court, Suite 100C, Pleasanton, CA 94566

Dynamic Mixer PP97 Parts

